

T: 619-77-ROSSI | 818-252-3811  
F: 818-252-3812  
E: info@RossiHardware.com

**Rossi**   
Innovating HVAC Hardware Since 1989

## SPEEDY ASSEMBLY INSTRUCTIONS

**1.** Drill 3/4" holes on each side of your sheet metal sleeve and click the Snap-In Bushings into place.



**2.** Holding the blade in position, pass the 3/8" square bar through the bushings and channel in the blade.



**3.** Spotweld or rivet the regulator in place, making sure the handle and blade are in corresponding positions.



**4.** Center the blade and secure the system with a self-drilling screw.

